



Food image courtesy of pinterest.com

Join thousands of **Modern Mums** using **Envirofit SuperSaver Jiko** for more recipes and tips!  
Contact our Customer Care centre on **0800722700**

### Ingredients

- 1 kg potatoes, peeled
- 1 cup all-purpose flour
- 1 teaspoon garlic salt
- 1 teaspoon onion salt
- 1 teaspoon salt
- 1 teaspoon paprika
- ½ cup water



### Preparation Method

1. Slice potatoes into French fries, and place into cold water so they won't turn brown while you prepare the oil.
2. Light your **Envirofit SuperSaver Charcoal Jiko** using little charcoal.
3. Heat oil in a large skillet over medium heat (reduce heat by slightly closing the **SuperSaver** air regulator). While the oil is heating, sift the flour, garlic salt, onion salt, (regular) salt and paprika into a large bowl. Gradually stir in enough water so that the batter can be drizzled from a spoon.
4. Dip potato slices into the batter one at a time, and place in the hot oil so they are not touching at first. The fries must be placed into the skillet little at a time, or they will clump together. Fry until golden brown and crispy. Remove and drain on paper towels.
5. Serve to your family and see them enjoy and want more!

**CALL FOR FREE TO BUY | FINANCING AVAILABLE**  
**PHONE: 0800 722 700 | EMAIL: [customercarekenya@envirofit.org](mailto:customercarekenya@envirofit.org)**